



The body of the splice should be centered between ## the two marking tapes and within 1/4" (6mm) of the inner edges of both marking tapes.

