

**RICHARDS
25KV**

CONNECTOR 1000 AWG
RICHARDS P6AL-28

3.06" [3 1/16"]

9.74" [9 3/4"]

14-12 PRE-SWAGE
INJECTION ADAPTER (IA)

**INSULATION CUT
BACK TEMPLATE**

TOOL STOP

260 MILS
INSULATION

SEMI-CON SHIELD

4.45" [4 7/16"]

6.69" [6 11/16"]

10.73" [10 3/4"]

MARKING TAPE

RICHARDS 62LCN1 or 62LCT1

SEMI-CON SHIELD

CABLE INSULATION ADAPTER
RICHARDS P625CA-N

**TOOL STOP CUT
BACK TEMPLATE**

**NOTE, THE INSULATION ADAPTER MUST
BE ON THE CABLE BEFORE SWAGING THE
CONNECTOR. SEE NRI 31 & NRI 32**

The marking tape must be located from end of strip cable (as shown as pre-swage) to the end of cable insulation adapter and should be within 1/4 inch [6mm] after swage...

RCH-25 62LC(N-T)1-N 1000 14-12 26mar10

© Copyright 2007, Novinium, Inc. All rights reserved.
IA is protected by patents and patents pending



novinium is a registered trademark of novinium.
(Printing instructions: For best results, print in color, protect w/5mil laminate and trim to size.)

SCALE: 1:1

8.5 x 22 paper size