

**RICHARDS**  
**15KV**

CONNECTOR 500 AWG  
RICHARDS P6AL-18

9.77" [9 3/4"]

2.69" [2 11/16"]

10-8 PRE-SWAGE (IA)  
INJECTION ADAPTER

**INSULATION CUT  
BACK TEMPLATE**

TOOL STOP

INSULATION  
220 MILS

SEMI-CON SHIELD

4.44" [4 7/16"]

6.30" [6 5/16"]

10.77" [10 3/4"]

MARKING TAPE

RICHARDS 62LCN1 or 62LCT1

SEMI-CON SHIELD

CABLE INSULATION ADAPTER  
RICHARDS P625CA-L

**TOOL STOP CUT  
BACK TEMPLATE**

**NOTE, THE INSULATION ADAPTER MUST  
BE ON THE CABLE BEFORE SWAGING  
THE CONNECTOR. SEE NRI 31 & NRI 32**

The marking tape must be located from end of strip cable (as shown as pre-swage) to end of cable insulation adapter and should be within 1/4" inch [6mm] after swage.

RCH-15 62LC(N-T)1-L 500 10-8 26mar10

© Copyright 2007, Novinium, Inc. All rights reserved.  
IA is protected by patents and patents pending  
Novinium is a registered trademark of Novinium.  
(Printing Instructions: For best results, print in color, protect w/5mil laminate and trim to size.)

**Novinium**

SCALE: 1:1

8.5 x 22 paper size